


Spray



Pneumatic charge sprayers need to be connected to an air compressor to charge the tank and allow the product vaporization without the connection to the air compressor. They work at high-pressures and so they use capacious steel or stainless steel tanks to allow a greater working autonomy.





	400 177 1874	455.07.00.00	
	SPRAY NV24	SPRAY NV50	
code	0.006.0002	0.006.0003	
capacity/model	24 l/painted	50 l/painted	
working pressure	6 bar	6 bar	
safety valve	max 8 bar	max 8 bar	
pressure indicator	pressure gauge	pressure gauge	
level indicator	external column	external column	
recharging	pneumatic	pneumatic	
ressure regulator	manual	manual	
jun connection	1/4" G-F	1/4" G-F	
ose type	rilsan	rilsan	
nose / lance lenght	10 mt / 600 mm	10 mt / 900 mm	
dimension / weight	28x32x75 cm / 15 kg - 33,06 lbs	45x42x100 cm / 25 kg - 55,11 lbs	